Technaxx®

IP–Security Camera for indoor and outdoor usage HD TX-24

User Manual

The Declaration of Conformity for this device is under:
www.technaxx.de/ (in bottom bar “Konformitätserklärung”)

Important Hint regarding the User Manuals:
All languages of the user manual (english, german, french, spanish, italian, netherlands, polish) you find on the CD-ROM enclosed.
The english and german version of the user manual you also find as printed version enclosed.

Contents

Before using the device the first time, read the user manual carefully.

1. Features & Product Description & Additonal Clamp Connections

2. Software Installation and Commissioning; Hardware Requirements

3. Hardware
3.1. Package contents
3.2. Hints for Environment Protection + Cleaning
3.3. Attention !

4. Getting Started
(Learn basic function to view and video in LAN and WLAN)
4.1. Video from a camera in the local network (LAN)
4.2. Set Wi-Fi connection
4.3. View the camera on the Internet (WLAN)
4.4. Register a new account and add devices
4.5. Main Menu

5. Video Surveillance (Control Panel)

6. General system settings
6.1. Camera Settings in LAN Mode
6.1.1. Set the IP Address
6.1.2. Set WIFI connection
6.1.3. Set the local video plan
6.1.4. MicroSD card configuration
6.1.5. MicroSD file download
6.1.6. Alarm alerts (Email)

6.1.7. Groups
6.1.8. Change the device alias
6.1.9. Dial connection (PPPOE)
6.1.10. Restore the default settings
6.2. Camera settings in WAN Mode
6.2.1. Groups
6.2.2. Change Access password
6.2.3. Change the camera alias
6.2.4. MicroSD card query
6.2.5. Installing MY SECURE

7. Settings on the Main Menu
7.1. Full screen
7.2. Settings
7.2.1. System
7.2.2. Video
7.2.3. Local Alarm Alerts
7.3. Device management
7.3.1. Add device
7.3.2. Change management password
7.3.3. Change watch password
7.3.4. Change camera alias

7.3.5. Permissions setting
7.4. Search
7.5. Change the password (User login password)
7.6. Log
7.7. Help


8. Frequently Asked Questions – FAQ
8.1. Video delay
8.2. LAN cable should not be too long
8.3. Cannot visit the IP camera in LAN
8.4. Can visit the IP camera in LAN, but cannot view it on WLAN
8.5. Image quality is not good enough
8.6. Forgot your password?
8.7. Restore to default settings
8.8. How to reboot equipment?

9. Technical Specifications

10. INSTALLATION MANUAL for Android / IOS Smartphone

1. Features & Product Description & Additonal Camp Connections

- Brilliant 1/4” CMOS colour sensor
- Supports P2P function, easy to connect through internet
- Alarmfunction, automatic alarm E-mails with image
- Direct Smartphone connection via QR-code APP
- QR-code scanning from the camera label produces immediate connection
- 36 IR–LEDs and IR night vision up to 20m
- Supports MicroSD memory card up to 32GB
- Video compress format: H.264 720p Multi Stream
- Supports 802.11.b/g/n wireless protocol
- Additional clamp connections to connect external alarm devices



IR–LED		Power line
Lens		Audio in
IR–Sensor		Audio out
QR code label		Reset
WiFi antenna		Alarm
		LAN port
		WLAN port

Additional clamp connections

This outdoor security camera has alarm function which can be connected to external alarm accessories like motion detectors, sirens, etc. Notice that alarm accessories are not (!) included in the delivery contents. The accessories must be closing over a power supply of 5-12V DC / Max. 300mA.

ALARM




IP CAMERA



SENSOR





NC (Normally Closed) **NO (Normally Open)**


2. Software Installation and Commissioning

Windows Requirements: WIN 7, WIN 8, Windows XP, Windows Vista

Hardware Requirements

- 1GB RAM and 2 Core CPU for 1 camera at 1 time
- 2GB RAM and i3 or updated processor for 4 cameras at 1 time
- REMARKS: No matter how many cameras you'd like to connect, this software has no requirement for GPU (Graphic Processing Unit)


Insert the software CD into the PC drive or download the software on http://www.technaxx.de/support/



Opening the CD and start the program "**My Secure.exe"**




Continue click “Next“ until the following steps were finished.



After installation finished, click below icon “**My Secure**” to run the software as shown.





3. Hardware

3.1. Package Contents: IP-Security Camera for indoor and outdoor usage HD TX-24, Power Supply, Network cable, Antenna and red cap for the antenna, Bracket and screws, Installation-CD with user manuals in **12** languages, User Manual (english and german version)

3.2. Hints for Environment Protection + Cleaning

Hints for Environment Protection: Packages materials are raw materials and can be recycled. Do not disposal old devices into the domestic waste. **Cleaning:** Protect the device from contamination and pollution (use a clean drapery). Avoid using rough, coarse-grained materials/solvents/other aggressive cleaner. Wipe the cleaned device.

Distributor: Technaxx Deutschland GmbH & Co.KG, Kruppstr. 105, 60388 Frankfurt a.M., Germany

3.3. Attention !


This device may only be operated with the supplied adaptor. Do not use or store the adaptor outdoor and do not operate the charger with moist or wet hands. Always remove the adaptor from socket if the device is not in use. Never open the device. The individual components of the device shall not be disassembled, repaired or modified. Unplug the device before cleaning or maintenance or connecting accessories.


4. Getting Started (learn basic function to view and video in LAN and WLAN)

4.1. Video from a camera in the local network (LAN)


Make sure the camera was plugged in adaptor and connected with router via LAN cable first. Run **“My Secure”** and click “LAN” on the right list area, then right-click the blank area, a menu pops out similar to Figure, select "Refresh" to get the camera list in the LAN. If there is a camera, double-click the camera ID to view the live video. If popped out a prompt like “request camera video failure!", check FAQ for help.







4.2. Set WIFI connection



(a) Click on the right mouse button then you see the device ID shown under LAN.

Then select "Set WIFI " on the menu popped out.


(b) Set SSID (Wireless router name) / Password

(1) Enable "Start WiFi setting".

(2) Click "Scan" to choose the WIFI connection "Network name [SSID]" (it is your Wireless router name).

(3) Wireless Security Type & Data Encryption will be selected automatically after the right Network Name (SSID) is selected. Please here no manual changes!

(4) Input the WIFI connection "Password" and click "OK" to save.



NOTE:

After saving WIFI settings the camera will restart automatically and then you can take off the LAN cable after the camera boots up successfully in 1–2 minutes and you see the camera ID in BLUE under LAN.

4.3. View the camera on the Internet (WLAN)


Click "Login" in the area of the main list on the right, input "User Name" (Cam/ID User) and "Login password" and click "Login" button. **The user name and password is on the label of the camera (see the picture below).**
The User name is: Cam ID/User, and the Password is: Login password




4.4. Register a new account and add devices

If you have many cameras, you also can register a new account, and add all cameras in the same account. In this case please insert the 4 digit number Access Code.


(1) Click "Register" and input user name / password /Email.




(2) Login in via the new account.



(3) Right click on the blank area ①, select “Add device” ② on the pop up window and input camera alias / Camera ID /Access password ③ (it is on the label of the camera).




(4) Double click the camera name to view video




Attention: when the camera lighting RED, that means the camera is in use!

4.5. Main Menu


Settings
Play back
Log
Fullscreen
Device Management
Change password
Help





(1) 

Full screen: View video in full screen.




(2) 


Settings:
Set System, Video, Local alarm, Alerts, Net.

(a) **System:** Set Program, Language, Set 3D option, Notifications, Update Please activate the 3D Option when you want to use Digital Zoom!


(b) Video: Set the folder of video recording and take picture / alarm view time




(c) Local alarm alerts: Set local alarm record time / capture time / alarm music.



(d) Net: Usually this is for development to test. Don't change anything.




(3) **Device management:** Add device / change password /set permission




(a) Add device

Add other camera to this account. This account will get the management authority.




(b) Change password

Change the device management Password.




(c) Change access code

Change the device access code (watch password).



(d) Change device alias

Change device name.




(e) Device restart


Restart the device remotely.

(f) Add permission

Set permission.




(4) **Playback:** Playback video on computer.




Attention:

Press 2x on the file you want to watch. The window opens (see left). Press with the right mouse button at the display of the window and after this you can use the buttons displayed on the below bar.

(5) **Change password:** Change login password.



(6) **Log:** Check system log.



(7) **Help:**

Software question and answer.

5. Video Surveillance (Control Panel)



CAUTION: some function is only for special camera!

(0)  Cruise (ON/OFF): Set cruise on, the camera will auto move rotate.

(1)  Optical zoom: control camera optical zoom +/-, only for the camera has optical zoom lens.

(2)  Digital Zoom: software support 4x digital zoom

(3)  Aperture switch: set camera aperture big or small

(4)  Capture: snap picture


(5)  Record: Record video on computer

(6)  Listen: listen to the camera audio on computer

(7)  Talk: talk with camera on computer

(8)  Set motion detection area: set the motion area (only for the camera which supports motion area. This is applicable to this TX-24 model itself.)

Set alarm sensitivity and set area (press left button and move to set area)



(9)  Horizontal pan (ON/OFF): set camera auto rotate horizontally


(10)  Vertical tilt (ON/OFF0: set camera auto rotate vertically

(11)  Go to pre-set position: call the camera preset (1-8)

(12)  Set preset position: set camera preset.(1-8)

(13)  Set PTZ speed : set camera rotate speed (1-10, 10 is fastest)


(14)  Vertical flip





(15)  Mirror






(16)  Set up wireless:


Enable “Start WIFI setting” and click on Scan to search wireless router signal and select the right wireless router name, input password. Then press OK.

After set WIFI, the camera will auto restart in 1–2 minutes.




(17)  Alarm log:

The camera alarm log




(18)  Setting:

Set device properties



6. General System Settings


6.1. Camera Settings in LAN Mode



Run the **My Secure.** All cameras will display in the LAN device list, double click the camera name to view the camera video. Right-click the device to set the camera parameter!

H.264/MPEG4 player (Better image quality)
Sub-Stream Player (Normal image quality)
View all the devices in this group
Close H.264/MPEG4
Close Sub Stream
Close all videos in this group

6.1.1. Set the IP address



The default setting is camera use DHCP. Camera auto gets IP address from network router.

It is a easy way for normal customer who do not know how to set IP address manually.


6.1.2. Set WIFI connection


(refer to 4.2. WIFI connection)

Activate the „Start WiFi Setting“ and click on Scan. Select your “Router” Network Name and put the right password from your WiFi router. Here no more changes! Then press OK.

6.1.3. Set the local video plan


Set local video record plan, the software will auto record the camera schedule on the computer after the **My Secure** is running, as shown below:
Enable “7 x 24” to record all the time from Sunday to Monday
Click “Add” to select the day it and set the start and End time for video recording
Click “Apply” to save the current video equipment plan settings.






6.1.4. MicroSD card configuration


Turn off the camera, then insert the MicroSD card and turn on the camera, after boot up. First format the MicroSD card. It also does not support hot swapping.




Insert a MicroSD memory card:
(1) Formatting a MicroSD* Card (*not in delivery) in Windows with FAT32.
(2) Remove the 4 screws at the rear side of the camera.
(3) Pull out the rear part of the camera a little bit, in order to see the MicroSD card slot (which is the part of it).
(4) Insert the MicroSD card into the card slot (is in the rear part of the camera).
(5) Push back the rear part of the camera in to the housing and fix it with the 4 screws.




The camera auto records video to the MicroSD card when there is motion alarm.



The camera auto records video to the MicroSD card when the camera external sensor gets alarm.




The camera auto continue records after the camera boots up.




The camera auto coverage the old video file when the MicroSD card is full.




The camera record audio to the MicroSD card.



Select the record video stream




Set the video file size.




Set video uploading to FTP server. FTP server can be only useful when MicroSD card has been plugged in.

6.1.5. MicroSD file download

Click “Search” to search the video file on the MicroSD card. Double click the file to download, double click the file to Playback after downloaded.



6.1.6. Alarm alerts (Email)




First enable the camera motion alarm function before setting the alarm alerts by Email.

Fill in the blanks of the pop-up window, click "OK". The device will automatically take photos and sent them to the email you set. (For example: the SMTP port for Gmail is 587; Yahoo use 465).


Alarm pictures: picture No. you want to the camera to snap.

Data encryption: To set the data encryption format depend on the email box supplier.(Gmail use TLS; Yahoo use SSL)



6.1.7. Groups

(1) Create a Group: Right click the camera ID and select “Create a group”. Enter a name for the group in the pop-up interface.




(2) Delete a Group: Right click the group name and click "Delete group" to display the pop-up box.

(3) Add the camera to the appropriate group: Select the camera ID, hold down the left mouse button to drag the camera to the group, and then release the left mouse button.


6.1.8. Change the device alias

Set a name that easy to remember for LAN camera. Right-click the camera ID and select “Change the device alias” to set a new name for the camera, as shown.




6.1.9. Dial connection (PPPOE)

Right click the camera ID and select “Dial connection (PPPOE)”:
Input user name and password of internet, and click “OK” to save.



6.1.10. Restore default setting

Right click the camera ID and select “Restore the default setting”, as shown:



REMARKS: Login password, watch password, and the parameters of the device like camera system, language, video parameter, will be restored to the factory setting. All those settings previously saved will be lost.

The manager for the device will not be changed back to the default manager.

6.2. Camera settings in WLAN mode


Inicie sesión en **My Secure** con la identificación de la cámara (o con una cuenta nueva registrada) y la contraseña.

. H.264/MPEG4 player
➔ (better image quality)
. Sub-Stream Player
➔ (Normal image quality)
. Close H.264/MPEG4
. Close Sub Stream



6.2.1. Groups

(1) Create a Group: Right click the camera ID and select “Create a group”. Enter a name for the group in the pop-up interface.




(2) Delete a Group: Right click the group name and click "Delete group" to display the pop-up box.

(3) Add the camera to the appropriate group: Select the camera ID, hold down the left button to drag the camera to the group, and then release the left mouse button.


6.2.2. Change Access password

After successfully login in, click right on camera ID, select “Change access code”, as shown:




6.2.3. Change the camera alias


Set a name that easy to remember For LAN camera. Right-click the camera ID and select “Change the device alias” to set a new name for the camera, as shown.



6.2.4. MicroSD card query

(a) Right mouse click on the camera ID and select the “SD Card query”.
(b) Click “Search” to obtain the file directory of the MicroSD card.
(c) Double-click the file to download.
Maximum 3 files are supported to be downloaded at the same time.





6.2.5. Installing MY SECURE

There are different kind of software can be used in our IP camera:

(1) MY SECURE: for Windows PC users



(2) My Secure: for Smartphone users like Android and iPhone.

Users can use different software above to see video from one IP camera.

NOTE: modifications on one IP camera through different software are simultaneous. In order to prevent disorder among modifications on different devices, we suggest each user should register one account for surveillance management only.


(3) QR-Code:

Except for logging in with the ID number and password on the sticker, users can also login automatically by scanning the QR-Code on the sticker. After clicking the "Scan QR Code" on the Smart Phone the scanning of the ID number and password starts automatically. Once the scanning is correct and finished, the live video will come out automatically via the mobile phone.



7. Settings on the Main Menu

Settings
Play back
Log
Device notify (not available)
Fullscreen
Device Management
Change password
Help




7.1. Full Screen

Live video in software will be in Full screen after click button “Full screen”. To exit the Full screen please click the button in the screen top right hand corner or “Esc” in the keyboard.

7.2. Settings

In “Settings”, user can do the setting for System, Video, Local Alarm Alerts and Net.

7.2.1. System




User can do the setting for “When closing the main window”, “Exit software”, “Notification”, “3D option”, “System Upgrade” and “Set program languages” by this page.

Remind to use “3D option” and “Set program languages to” will only be activated after restart the software.

7.2.2. Video

Default folder for capture and video recording can be set on this page.




The new video file will cover the old record by setting “Loop recording” if the hard disk space is not enough for video storage, user can assign the minimum available hard disk space in the PC by setting “Keep space over”

(The default setting of software is 2 GB).

“Alarm view time” means the duration showing the “Device alarm” message the top left corner when the motion detection alarm is activated. “Clear record”, “Clear picture file” and “Clear login record” also can be done by this page.

7.2.3. Local Alarm Alerts


Before setting the Local Alarm Alerts, complete the setting on motion detection area. To learn about the setting of motion detection area, refer to No. 5. “Video Surveillance“ (8) Motion detection area”.



Click “Settings”, and choose “Local Alarm Alerts” setting, as shown.
Local alarm record: Tick the box and set the “Alarm record time”. Camera will start to record after the set time reached
Local alarm capture: Tick the box and choose the alarm time interval when snap.
Local alarm music: Tick the box to set the audible alarm music you like
Click OK to confirm setting.

7.3. Device Management


Device management function is used to manage the permission for different device and different user. Before starting the device management, make sure you login with your account which you registered.



7.3.1. Add device

Input:

Device Alias
ID
Management password
Watch password
Set watch permission




REMARK:
Default management password and watch password equal to the device login password and Access code on the QR code label.

IMPORTANT:
Default Manager (User) for the camera is Cam ID / User on the camera label. Manager position will be changed to other user if other user clicking in the "Device management" with the correct management password (Login/ password on product QR code label).

One user can be the manager for more than one device.


If user forgets the password, click the restore button **(Refer to Section 6.1.10. "Restore the default settings")** and password will change back to the original password.

7.3.2. Change management password



Input the new management password (Equal to the login password in the QR code label), the new password will replace the login password of device on QR code label.


7.3.3. Change watch password




Input the new watch password (Equal to the Access code in QR code label) and set the watch permission, the new watch password will replace the Access code on QR code label.

7.3.4. Change camera alias

Set a friendly name easy to Remember for the camera.



7.3.5. Permissions Setting




This camera is private and protected, to limit the activity for registered user.

Management can assign different permission level to different user.

To set permission for different user, follow the steps below.

Add permission: Input the user name and search, then select the user name and set permission levels.




Change permission: Select the user name and click “Change Permission”, then select the level by “No right”, “Allow watch”, “Allow watch and record” and “Allow watch, record and operate”.

No right: Users are not allowed to watch the live video unless they know the watch password.


Allow watch: Users are allowed to watch live video.

Allow watch and record: Users are allowed to watch, capture and record live video.

Allow watch, record and operate:
Users are allowed to watch live video, capture and record live video, and change system settings, to control PTZ.




Delete permission:
If the user name is deleted, user will have the permission to watch IP camera if the user knew the watch password (Access code).




7.4. Search

According to recording time of the query video recordings on the local computer, double-click the video file to playback.
NOTE: Video playback support for pause, slow down, fast forward, drag the progress bar and other operations.




7.5. Change password (User login password)

When login successfully, you can click "Change Password" button on the menu bar, pop-up window, input the original login password and new password.



7.6. Log

User can check the Log History by clicking on the “LOG” icon.





7.7. Help

User can check the user manual by HTML format by clicking on the “Help” icon on top left main menu.

8. FAQ (Frequently Asked Questions)

8.1. Video delay: There are three factors which will cause video delay: upload speed, PC download speed, and image resolution. If the issue happens on the PC client, generally, you can click “Settings” as below to adjust the resolution to QVGA (320 x 240). If it also does not work, please check the other two factors.






8.2. LAN cable should not be too long

If network cable is too long, the signal will be weakened and cause disconnection. Any network fault on PC client or IP camera will cause video disconnection.

8.3. Cannot visit the IP camera in LAN

1. Check, if the network cable is connected ok.

2. Right mouseclick on LAN and select “Set the IP address”. Normally the device will automatically get an IP address. If not, you have to set manually the same Subnet IP address for the device.




8.4. Can visit the IP camera in LAN, but cannot view it on WLAN

When camera can be viewed on LAN, but cannot be viewed via WLAN, usually because the device gets wrong IP address. Try to set DHCP for the device


8.5. Image quality is not good enough


All of the camera parameters keep default value of factory, but not all the parameters are proper for special occasions. The default setting is based on factory testing environment. Users can adjust parameters according to his environment to get a good video. You can adjust the parameters like resolution to get better quality images according to your requirements.



8.6. Forgot your password?


If you have forgotten your own login password which registered by yourself, click “Forgot Password”. Input your username and your registered email address. The server will send a password to your mail box. Then use the new password to login.





Please check your Email





8.7. Restore to default settings

(a) Press the reset button of the camera about 1 minute.
(b) Right-click camera ID on LAN, click “Restore to default setting”.

8.8. How to reboot equipment?

User can reboot equipment whatever he/she is in local network or Internet. If the user is in LAN, right-click the device and select “Device restart”. If the user is in WLAN, click “Device management” and click the “Device restart”.

9. Technical Specifications

Image Sensor	1/4" CMOS colour sensor
Minimum illumination	0.5 Lux
Waterproofed	IP65
Video compression	H.264 720p Multi Stream
Internet connection	Supports P2P function, easy to connect through internet
Video frame rate	25fps
Motion detection & Capture	Yes / Yes
Video (adjustable)	Brightness, Contrast, Sharpness, Saturation
Digital Zoom	4x Digital Zoom
Audio output	One audio output
Audio format	G.726
System interface	Audio input/output
	Alarm input/output
	10Base-T / 100Base-TX internet interface
Video stream	16Kbps ~ 4Mbps
Protocol	TCP / IP
Wireless network	Supports 802.11.b/g/n wireless protocol
Memory card	Supports MicroSD card up to 32GB
Infrared lights	36 IR–LEDs
IR night vision	20 m
Alarm input	One-way high level input
Alarm output	One-way DC5V 300mA output
Power supply	External power adaptor DC 12V / 1A
Power consumption	4 W
Working temperature	–5°C up to +55°C
Weight / Dimensions	725g (with cable) / (L) 26 x (W) 7 x (H) 16cm

10. Installation Manual

for Android / IOS Smartphone

Install IP Camera ➔ Install Mobile Phone App Technaxx **My Secure** Software ➔ Register an account ➔ Add cameras under this account


IP Network Camera Installation Procedure

First plug in the power cable to the IP camera. Then connect the LAN cable with the camera and the rourter (see picture below).

ATTENTION: DHCP service

must be enabled in the router!






(1) Before installation, make sure your phone is using 3G or WIFI

(2) Install software: Search and Install “My Secure” in Apple APP store and Google play store.





(3) Click the APP icon to run the mobile APP



(4) Input the camera ID and password to Login camera

The **My Secure** icon (see below) you can find on the LOGIN screen right hand side (see the picture of the LOGIN screen). Also support click this icon to scan QR-code to auto input ID and password. Then check the camera label and input ID and password on the APP






My Secure icon




(5) Login account. (If no accounts yet, go to register an account first and type in User name and Password). Under this account you can add Security CAM's (go to point 10)

(6) After successful login, click on a camera to start monitoring.



(7) Press at the “+” symbol to add a camera



1.Add other camera

2.Play camera video


3.Config camera

4.Camera list in WAN

5.Camera list in LAN

6.Video playback

7.Alarm events



1.Select video resolution

2.preset operation

3.Audio talk


4.Snap Picture

5.Single screen and quad


6.Video record


(8) Setting Camera under sub menu WAN

Set video quality parameters and SD card, by clicking the sign. [under iPhone; under Samsung].



ATTENTION: The configuration of the cameras is only under “Online” status possible!





Automatic recording starts when enough disc space on the MicroSD card exists **(Attention: only for TX-24).**


Video partition size can be defined how much MB for each stream.


Video settings: Select between sub-stream & main-stream.

Quality: select the quality of the video (low, normal, high, good, super


Set for Resolution, Frame rate & Stream accordingly.










(9) Setting Camera under sub menu LAN



45% 16:05
Cameras
E318458
Online
WAN
Files
Alarms
More



45% 16:05
Settings:E318458
Ethernet
Wi-Fi
Video settings
Cloud
SD-Card settings
SD-Card query
E-Mail
Alarm settings
System Settings



45% 16:06
Wi-Fi
Use wifi
Colse wifi
Ok
Cancel



45% 16:05
Ethernet
Use DHCP
IP
192.168.18.101
Subnet mask
255.255.255.0
Gateway
192.168.18.1
DNS
120.80.88.88
Ok
Cancel



57% 15:11
Video settings
sub-stream
main-stream
Quality Custom
Resolution VGA(640*480)
Frame rate 12
Stream 100 kb
Ok
Cancel


45% 16:06
Cloud
Protocol FTP
URL
Port
0
User Name
Password
Ok
Cancel



45% 16:06
MicroSD-Card settings
Start automatic recording
Voice recording
Video partition size
2
MB
SD-Card total capacity 0 MB
SD-Card used capacity 0 MB
SD-Card remaining capacity 0 MB
Format Micro SD card
Ok
Cancel


46% 16:04
MicroSD Card Query
Loading...
Cancel





You can select to enable or disable motion detection & select the sensitivity (highest, high, medium, low).




Control Pan/Tilt

Taking photo

Recording video


After the connection to the camera is established, you see at the bottom of the Display the following symbol:



Press the button (a) then you find the following picture you can select video resolution:


HD = 1300 kbps
Smooth = 800kbps
Faster = 400 kbps

When you press the button (b), you can take a picture directly from the Security Cam.







Button Description



To remove/replace, replace the picture simply press & hold at each picture and select.





Press the button ⓒ to hear over headphone or to speak through microphone. Connect your headphone to your Smartphone or press on the microphone to speak.



Press the button ⓓ to take a picture one by one. Press the button ⓔ to see a single windows or quad.

Press the button (f) to start recording a video.







Press the button (g) to adjust or change the direction of the Security CAM. **(Attention: this menu functions only for TX-23!)**



You can also move the direction of the camera by pressing &

holding the menu for each direction:








Press ❶ to rotate the Security CAM horizontally.

Press ❷ to rotate the Security CAM vertically.

Press ❸ or ❹ to invert the Security CAM down or up.




Press the button to adjust the color of the Security CAM:

Hold & move a button to the right or left to change brightness.

Hold & move to the left or right to change the contrast of the picture.

(10) Register account (if successfully being registered, jump back to Step 3):


Press “Register”; Fill in information; Click “OK” to complete it




(11) Add cameras under account (if successfully being added, jump back to step 4)

Login first; Click “+”

Click “Add Device” or Scan to add a device automatically (***QR Code***)
Camera Alias = here you can give a name which you like.
Camera ID = find this ID under your Camera written with QR Code.
Access code = find this code under your Camera.








Focus the smart phone camera directly at the QR Code of the security cam.

Fill in camera information

"**Device Alias**" – give a name to this camera
"**Device ID**" – at bottom of each camera, there is a label with QR Code
"**Access Pass.**"

Click "Done" to add it



At the end: If successfully being added, the new camera will be in the list.

